

Pocket Press Application Recommendation



Use the included 3M Cavilon™ skin protectant wipe prior to applying the Pocket Press pressure dressing.

Simply wipe one layer of the Cavilon over any skin that will be taped. Allow to dry for 30 seconds, then apply the Pocket Press.

The Cavilon wipe will form a thin, protective barrier to help protect the patient's skin when the Pocket Press is removed.

